



**A. 333-5060**

32 oz. Coffee Pot

**B. 333-5057**

64 oz. Water Pitcher  
W/O Ice Guard

**C. 333-5061**

64 oz. Coffee Pot

**D. 333-5059**

18 oz. Coffee Pot

**E. 333-5050**

10 oz. Creamer

**F. 333-5058**

10 oz. Coffee Pot

**G. 333-5053**

10 oz. Sugar Bowl