



**A. 333-1141**

64 oz. Water Pitcher

**B. 333-1139**

32 oz. Coffee Pot

**C. 333-1140**

64 oz. Coffee Pot

**D. 333-1138**

18 oz. Coffee Pot

**E. 333-1133**

10 oz. Sugar Bowl

**F. 333-1136**

10 oz. Creamer

**G. 333-1137**

10 oz. Coffee Pot

**H. 333-1135**

5 oz. Creamer

**I. 333-1134**

5 oz. Sugar Bowl